
1. Unlocking Talking Pen Security Mode


Requirements:

- A computer with a USB port
- Talking Pen (with batteries inserted)
- USB Type-C data cable (not a regular charging cable, but a genuine charging cable with data transfer functionality typically provided with smartphones)


1) Press and hold the power button and volume button on the Talking Pen simultaneously.
2) While keeping the buttons pressed, connect the USB Type-C data cable to the Talking Pen.
3) After 1 to 2 seconds of connecting the data cable, release the buttons.



2. Access the generated Talking Pen drive and delete all files.



***The generated drive**




***Delete all files in the drive.**

3. Copy the files from the attached BTP folder to the Talking Pen drive.

Caution:

1) Only copy the files within the BTP folder
   :Total of 8 files
   (refer to the image on the right for confirmation).
2) Do not change the file names.
3) Do not store any files other than the provided
   audio compression file in the Talking Pen drive.



4. Disconnect the Talking Pen from the USB cable and proceed with normal usage.